

Aspire Nautilus CF Starter Kit

Thank you for your purchase of the Aspire Nautilus tank + Carbon Fibre (CF) Battery starter kit system.

Before using the Nautilus, please read through the manual for proper care and use. This will insure continued enjoyment of your Nautilus Tank. Please keep manual for future reference.

The Nautilus has an exclusive adjustable airflow design that is revolutionarily. With a simple turn of the lower ring, you have four options to adjust airflow to meet people's different requirements for vaping. With the option of different size air-ports, it allows the user to produce big clouds of vapor, with a pure and clean taste. With the unique Nautilus four-port system, you can now adjust how hard or soft the draw is, how warm or cold the vapor is, and how much vapor is produced. The Nautilus is also very easy to install and refill.

Aspire...the trusted name in Personal Vaporizers.

Configuration




Contents of kit:

- * Complete Nautilus Tank (1.6 ohm atomizer pre-installed)
- * 1 replacement atomizer (1.8 ohm)
- * 1 eGo threaded cone
- * 1 user manual
- * 1 Aspire Carbon Fibre battery (VV or VV+ based on the kit)

How to use Nautilus Tank

Nautilus Exploded View



How to use Nautilus Tank

How to assembly

1. Screw the upper hardware to the Pyrex tank (DO NOT over tighten!).



2. Screw the BDC Atomizer into the bottom hardware (make sure the BDC atomizer is snugged down hand tight).



How to use Nautilus Tank



How to assembly

3. Snugly screw the Tank hardware to the bottom Atomizer hardware (the atomizer screws onto the air-tube shaft in center).



4. Insert the drip-tip into the upper hardware.

How to use Nautilus Tank

How to fill liquid

1. Check to make sure the upper stainless steel be screwed tightly onto the glass tank.



2. Screw the bottom hardware off the upper hardware.



How to use Nautilus Tank

How to fill liquid



When you screw off the bottom hardware, the atomizer should be screwed off the upper hardware at the same time, in case the atomizer is still kept onto the air-tube shaft in center, please screw the atomizer off and screw back onto the bottom hardware in order to avoid disconnecting.

How to use Nautilus Tank

How to fill liquid

3. Fill liquid into the space between the glass tank and the center metal tube. DO NOT over fill or get liquid into the center shaft.



4. Screw the bottom hardware back onto the upper hardware.



How to use Nautilus Tank


How to fill liquid



- A: Don't fill the liquid into the central hole.
- B: Let the Nautilus stand for 2 minutes before use—this will let e-liquid absorbed into the wick/atomizer chamber.
- C: For use with eGo batteries: screw the supplied cone onto the threads, and then install the Nautilus onto the battery.
- D: If you experience a burning taste the first couple of puffs, it's because the liquid has not absorbed into the wick. Give the liquid time to be absorbed and try again.

How to use Nautilus Tank

How to adjust airflow



The Nautilus unique airflow valve features 4 different sizes to control the airflow to the amount you prefer. Rotate the Airflow control valve to the most comfortable one for you.

When necessary, clean the components (except the BDC Atomizer) by washing with clean water, and air-drying the components.

NOTICES

1. The glass tank should not be impacted, dropped, or mishandled, otherwise the glass tube may be broken, and injury may occur.
2. When disassembling, please remove the bottom hardware first, and then screw off the glass tank.
3. Do not fill the Aspire Nautilus over 5ml; when the liquid level is below 0.5ml, should be refilled to avoid a dry wick.
4. If the bottom hardware is hard to be screwed off, please screw the upper hardware with the glass tank tightly and then the bottom hardware will be easy to screw off.

How To Use CF Battery

1. Turn ON/OFF

Press button 5 times in succession in 2 seconds. The LED will blink 3 times (both blue and orange lights) and the button will illuminate Blue when active and ON.

Repeat this procedure to turn battery OFF.

2. Usage

Once battery is ON, Press the LED button and inhale at the same time.

3. LED Light Indicator

The Blue LED light will display for battery cell voltage of 3.5-4.2V.

The Orange LED indicates a voltage less than 3.5V. Output Voltage 4.2V

How To Use CF Battery

4. How to change Variable Voltage settings

Rotate the rotary knob at the bottom of the battery to deliver the optimal voltage for vaping needs. Aspire CF VV battery allows for stepless variation in 3.3V-4.8V output variable voltage.

5. Low Battery Indication

The battery Orange indicator light blinks 15 times.

6. Overcharge & Over-discharge Protection

When battery is overcharged (voltage beyond 4.25V), the built-in microchip will automatically stop battery charging.

When battery cell voltage is less than 3.2V (low battery), the atomizer will remain OFF, and the Orange LED light will blink 15 times.

How To Use CF Battery

7. How to Charge

1. Unscrew the battery from the vaping components.
2. Gently screw battery into the USB charger.
3. Plug the USB into the supplied wall charger or computer.
4. The battery will flash 3 times and then turn solid in color (Orange light in 3.2-3.5V, Blue light in 3.5-4.15V).
5. The light on the USB charger will be red when charging.
6. Once fully charged, the USB charger will display a green light, and the LED light on battery will blink 20 times (blue), then turn off. -

See more at: <http://www.aspirecig.com/products/aspire-cf-battery-series/cf-battery-150.html#sthash.kDifIrd5.dpuf>

How To Use CF Battery

8. Atomizer Short Circuit Protection

If heating coils are short-circuited while vaping, the LED lights (both colors) blink 3 times, and the battery will default to “sleep mode.”

9. Charging Short Circuit Protection

If the charger is short-circuited while charging, the battery will default to OFF position, stop charging, and the LED lights (both colors) will flash 6 times.

10. Lock and Unlock Function

To lock the battery, press the button 5 times in succession in 2 seconds. The LED lights (both colors) will flash 3 times. Repeat this procedure or recharge to unlock.

See more at: <http://www.aspirecig.com/products/aspire-cf-battery-series/cf-battery-150.html#sthash.kDifIrd5.dpuf>